


MARATHON PRODUCTS, INC.



EZ Logger Initialization Instructions:

Start the **MDAS-Pro software** by double clicking on the icon.

Select **EZ Logger** on the menu.

Select **Logger Initialization** on the drop down menu.

The Logger Initialization screen will appear.




SET UP SCREEN:

Enter a description of the current recording that will remind you what the contents are at a later date.

The EZ Logger is synchronized to your computer's date and time.


Click **Next**.



MEASUREMENT SCREEN:

Measurement lets you set the interval between measurements. The length of the interval determines the total duration of the recording time. Setting a shorter interval gives a shorter total duration. A larger interval gives a longer total duration. The minimum interval is 10 seconds.

Click **Next**.



START TIME SCREEN:


Click on one of the options on how you want the EZ Logger to start recording.

Start Immediately will start recording immediately after initialization.

Start Time lets you set a date and time for the recording to start.

Start Delay lets you set a delay before starting the recording.

Click **Next**.



ALARM SCREEN:

Alarm lets you set the High and/or Low Temperature Alarm conditions, and the High and/or Low Humidity Alarm conditions. Select and set as required, or leave them blank.

Click **Next**.

This will start the logger recording or begin the start delay count down.

