

MARATHON PRODUCTS

# TempCheck2

## Single-use Strip Chart Temperature Recorder

The TempCheck2® is a reliable and cost-effective strip chart temperature recorder for all shipping and transit applications. The TempCheck is driven by a high-torque quartz motor and displays the time and temperature on strip chart paper in both Celsius and Fahrenheit.



MARATHON  
PRODUCTS, INC.



*Don't ship  
without us!®*

### Full Serialization:

The recorder and the strip chart share the same serial number for positive identification.

### Factory Sealed:

A unique feature is the silver polyester tamper evident seal. If any attempt is made to remove the seal, the word VOID appears on the seal and the case.

### Verification:

Marathon offers, at no cost to the user, a post-trip verification service. Simply return the instrument for us to check and verify the accuracy against our NIST traceable standards.

### Recycle:

TempChecks are for single use only but we encourage recycling. Please call Marathon for disposal or recycling of these units.

Note: a minimum order consists of 24 units; product shipment is Same Day if the order is placed before 2pm Pacific Standard Time.

For information on the TempCheck2 Strip Chart Temperature Recorder please contact Marathon Products.

TempCheck 2 Specifications	
Run Time	7 days; 16 days; 30 days; and 60 days
Operating Range	-13° to +95°F (-25° to +35°C)
Accuracy	±2°F (±1°C)
Thermal Sensor	Bi-metal coil
Drive Source	Solid state quartz-controlled motor
Power Source	One AA 1.5 volt carbon zinc battery, mercury free
Size	5.55 in (L) x 4.92 in (W) x 2.68 in (H) 14.1 cm (L) x 12.5 cm (W) x 6.8 cm (H)
Weight	11.4 oz (323 g)
Simple Starting Procedure	1. Fill in documentation tag 2. Peel off top tag 3. Pull and remove start tab
Wall mounting options	Self-adhesive double foam tape
CE Certified	Yes
Carton	
Quantity	24 units
Weight	18.7 lbs (8.47 kg)
Size	15.25 in (L) x 11.25 in (W) x 11.5 in (H) 38.73 cm (L) x 28.57 cm (W) x 29.21 cm (H)



**Please call 1-510-562-6450 x604**  
for more information or to place an order.

[www.marathonproducts.com](http://www.marathonproducts.com)

627 McCormick St., San Leandro, CA 94577 ▪ [sholt@marathonproducts.com](mailto:sholt@marathonproducts.com)