

MARATHON PRODUCTS

# TempCheck3<sup>®</sup>

## Single-use Strip Chart Temperature Recorder

The TempCheck3 is a reliable and cost-effective strip chart temperature recorder for all shipping and transit applications. The TempCheck3 is driven by a high-torque quartz motor and displays the time and temperature on strip chart paper in both Celsius and Fahrenheit.



MARATHON  
PRODUCTS, INC.



Don't ship without us!<sup>®</sup>

### Full Serialization:

The recorder and the strip chart share the same serial number for positive identification.

### Factory Sealed:

A unique feature is the silver polyester tamper evident seal. If any attempt is made to remove the seal, the word VOID appears on the seal and the case.

### Verification:

Marathon offers, at no cost to the user, a post-trip verification service. Simply return the instrument for us to check and verify the accuracy against our NIST traceable standards.

### Recycle:

TempChecks are for single-use only but we encourage recycling. Please contact your local E-Waste for proper recycling of these units.

Note: a minimum order consists of 24 units; product shipment is Same Day if the order is placed before 2pm Pacific Standard Time.

TempCheck3 Specifications	
Run Time Options	SKU #8098: 7 days, SKU #8095: 16 days, SKU #8096: 30 days, SKU #8097: 60 days
Operating Range	-13° to +95°F (-25° to +35°C)
Accuracy	±2°F (±1°C)
Thermal Sensor	Bi-metal coil
Drive Source	Solid state quartz-controlled motor
Power Source	One AA 1.5 volt carbon zinc battery, mercury free
Size	4.75 in (L) x 4.25 in (W) x 2.5 in (H) 12.1 cm (L) x 10.8 cm (W) x 6.4 cm (H)
Weight	0.46 lbs. (0.2 kg)
Simple Starting Procedure	1. Fill in documentation tag 2. Peel off top tag 3. Pull and remove start tab
Wall mounting options	Self-adhesive double-sided foam tape
CE Certified	Yes
Carton	
Quantity	24 units
Weight	13 lbs (5.9 kg)
Size	15 in (L) x 11 in (W) x 10 in (H) 38.1 cm (L) x 27.9 cm (W) x 25.4 cm (H)



New clear top lets you check the status without opening the recorder.

**Please call 1-510-562-6450**  
for more information or to place an order.

**www.marathonproducts.com**

627 McCormick St., San Leandro, CA 94577 ▪ sholt@marathonproducts.com  
Specifications subject to change without prior notice.